



- 1** Choose the desired mounting height of the towel rail and unscrew the nuts only at this position for about  $\frac{13}{64}$  (0.5), using a picklock with width  $\frac{23}{64}$  (1.3).
- 2** Push the slots of the towel rail over the bolts in between of the back of radiator and the sealing ring.
- 3** Push the towel rail over the top end of the Geo to the desired height. Pay attention not to damage the radiator.
- 4** Tighten the nuts firmly.